

**AA 07-058 maintenance stages
for performance class 3.3 and 4.0 from ID 5.000
From year of construction 01.2019**

Explanation of the maintenance stages for the neoTower®

Please note that only one maintenance set per maintenance is required.

For all maintenance stages, the fluids must be ordered separately. They are not included.

Oe1 = oil change
 W1 = regular maintenance
 W2*1 = regular maintenance + caloric value heat exchanger
 W3*2 = regular maintenance + engine
 W4*2 = regular maintenance + generator
 W3/4*2 = regular maintenance + engine + generator

*1 According to findings, the operating hours indicated in the maintenance levels are average guide values and may deviate.

*2 According to findings, the operating hours indicated in the maintenance levels are average guide values and may deviate. If the caloric value heat exchanger needs to be replaced, it must be ordered separately.

Maintenance stages
Performance class 3.3 and 4.0

Maintenance interval (OPHRS) or every 2 years	6.500	13.000
Operating hours	Oe-stage	W-stage
6.500	Oe1	
13.000		W1
19.500	Oe1	
26.000*1		W2*2
32.500	Oe1	
39.000		W1
45.500	Oe1	
52.000*1		W3*3
58.500	Oe1	
65.000		W1
71.500	Oe1	
78.000*1		W2*2
84.500	Oe1	
91.000*1		W4*3

*1 According to findings, the operating hours indicated in the maintenance levels are average guide values and may deviate.

*2 The maintenance stage may change depending on the findings.

*3 The maintenance stage may change depending on the findings. The caloric value heat exchanger is not part of the maintenance set and must be ordered separately.

General notes:

- In order to prevent damage to the plant - which can be caused by exceeding the maintenance intervals or maintenance levels - an automatic shutdown takes place when the maintenance has been exceeded by 200 operating hours.
- When the last maintenance level is reached, the cycle starts again from the beginning.